









<p>Record your model number.</p>	<p>⚠ WARNING: Risk of scalding. High water temperature can cause severe burns. Set the water temperature at or below 120°F (49°C) following the adjustment procedure in the valve's installation instructions at Kallista.com.</p>	<p>⚠ WARNING: Risk of scalding. This valve will not protect against scalding if incoming water temperature changes significantly during operation.</p>	<p>⚠ CAUTION: Risk of product damage: Use only silicone based lubricants with this product. Other lubricants may cause damage.</p>	<p>Important Information If installing to the P19310-00-NA or P19310-WS-NA valves, follow the service kit instructions in the Pressure Balance Valve Kit.</p>
<p>1 Remove the plaster guard.</p> 	<p>2 Tiled Wall Installation Only: Apply sealant to the back of the seal plate.</p> 	<p>3 Break off the tab. Install the backplate with the large hole/diverter hole positioned at the bottom.</p>  <p>Tab</p>	<p>4 For Diverter Valves Only: Install the gasket and button. Secure with the setscrew. Install the guide.</p>  <p>5/64"</p>	<p>5 Fit the diverter seal over the diverter actuator (if applicable).</p> 
<p>6 Install the faceplate. If the collar does not engage, loosen the seal plate screws.</p> 	<p>7 Tighten the collar with the notched tool. Do not overtighten!</p> 	<p>8 Install the sleeve and handle. Secure with the setscrew.</p>  <p>1/16"</p>		

Questions? Problems? For additional assistance, please contact
KALLISTA's Customer Service Department at 1-888-4-KALLISTA
(1-888-452-5547) or kallista.com.