QUOIZEL
LIGHTING®

INSTALLATION GUIDE FOR
OTN1512MBK and OTN1712MBK

⚠ SAFETY INFORMATION

Please read and understand this entire manual before attempting to assemble, install or operate the product.

WARNING
- RISK OF ELECTRIC SHOCK - Before beginning installation, turn off electricity at the circuit breaker box or the main fuse box.
- RISK OF FIRE - Use bulbs specified by the markings and/or labels on the fixture.

CAUTION
- For your safety, read instructions completely before beginning installation.
- If in doubt about electrical installation, consult a licensed electrician.
- Turn off electricity to fixture before replacing the bulb(s).

TOOLS REQUIRED

CARE AND MAINTENANCE

- Wipe clean using soft, dry cloth or static duster. Always avoid using harsh chemicals and abrasives to clean fixture as they may damage the finish.

If you need further assistance call Quoizel Customer Care at 1-800-645-3184 (9:00am - 5:00pm EST), or visit us on-line at www.quoizel.com.

PACKAGE CONTENTS

A Fixture Loop x 1

B Rod x 1

C Socket Assembly x 1

D Glass Shade x 1

E Socket Collar [preassembled to Socket Assembly] x 1

MOUNTING HARDWARE

AA Crossbar x 1

BB Mounting Screw x 2

CC Wire Connector x 3

DD Outlet Box Screw x 2

EE Ceiling Canopy x 1

FF Quick Link x 2

GG Fixture Chain x 1

## OPTION 1: PENDANT - OTN1512MBK

1 **Install Rod and Fixture Loop**

**2** **Tighten Hex Nut inside of Ceiling Canopy**


3 **Install Fixture Chain**

OPTIONAL: Adjust Chain as desired, using pliers and soft cloth (neither included).

Suggested chain length for Ceiling height:
8 feet ceiling: use 13 links of chain and 2 quick links
9 feet ceiling: use 23 links of chain and 2 quick links
10 feet ceiling: use 33 links of chain and 2 quick links.

4 **Pull Supply Wires**

Pull the supply wires with ground wire through the chain alternate links.


5 **Install Crossbar**

Outlet Box

6 **Wiring**

White wire from supply

Ribbed side of wire from fixture identified with the label "N"

Black (or red) wire from supply

Smooth side of wire from fixture identified with the label "L"

Ground wire from supply

Ground wire from fixture identified with the label "G"

Green ground wire

INSTALLATION

7 | **Install Ceiling Canopy to Crossbar**

8 | **Install Glass Shade and Bulb**

Install the correct bulb referring to fixture markings and/or labels for maximum wattage.

**Recommended Bulb Type (not included):**

100W MAX

BULB BASE TYPE
Medium (E26)

BULB TYPE
TYPE A

**Your installation is now complete! Restore electricity and save this sheet for future reference.**

IMPORTANT: This CONVERTIBLE fixture can be mounted as pendant light or semi-flush light. **DO NOT CUT SUPPLY WIRES** if you intend to use it as pendant light.

OPTION 2: SEMI-FLUSH - OTN1712MBK

* Set aside *Fixture Loop, Rod, Quick Link* and *Fixture Chain* since they are not required for the semi-flush installation.


1 | **Remove Loop from Ceiling Canopy**

* Set aside *the Loop with nipple* since they are not required for the semi-flush installation.

**2** | **Install Ceiling Canopy to Socket Assembly**

3 **Install Crossbar**

Outlet Box

4 **Wiring**

Cut supply wires and leave approximately 8" from ceiling canopy.

White wire from supply — Ribbed side of wire from fixture identified with the label "N"

Black (or red) wire from supply — Smooth side of wire from fixture identified with the label "L"

Ground wire from supply — Ground wire from fixture identified with the label "G"

Green ground wire

5 **Install Ceiling Canopy to Crossbar**

6 **Install Glass Shade and Bulb**

Install the correct bulb referring to fixture markings and/or labels for maximum wattage.

Recommended Bulb Type (not included):

100W MAX

BULB BASE TYPE
Medium (E26)

BULB TYPE
TYPE A

Your installation is now complete! Restore electricity and save this sheet for future reference.